



Item	Part No	Description	Qty
1	8958001402	Bracket assembly	1
3	8958001403	Pressure release base assy	1
4	8958001404	Piston	1
6	8958001406	Outer sleeve	1
7	8958001408	Oil tank	1
17	8958001451	Filter net	2
19	8958001375	Manifold block assy	1
58	8958001409	Oil plug assy	1
<b>A</b>	<b>8958001354</b>	<b>Foot pedal kit</b>	
30	-	Shoulder screw	1
31	-	Flat washer	1
32	-	Pedal assy	1
33	-	Idler wheel	1
34	-	Shaft circlips	1
35	-	Pedal rubber pad	1
<b>B</b>	<b>8958001355</b>	<b>Oil absorbtion valve kit</b>	
14	-	Plug	2
16	-	Steel ball	2
18	-	Spring	2
<b>C</b>	<b>8958001356</b>	<b>Oil taking check valve kit</b>	
14	-	Plug	2
15	-	Tower spring	2
16	-	Steel ball	2
<b>D</b>	<b>8958001357</b>	<b>Low pressure valve kit</b>	
14	-	Plug	1
20	-	Cone valve	1
21	-	Low pressure adjusting spring	1
22	-	Pressure adjusting screw	1
<b>E</b>	<b>8958001358</b>	<b>Safety valve kit</b>	
14	-	Plug	1
22	-	Pressure adjusting screw	1
23	-	Steel ball	1
24	-	Steel ball holder	1
25	-	Pressure adjusting spring	1
<b>F</b>	<b>8958001359</b>	<b>Pump kit</b>	
36	-	O Ring	1
37	-	O Ring	1
38	-	Oil pump body	1
40	-	Big pump return spring	1
41	-	Small pump plunger	1
42	-	X-Ring	2
43	-	Big pump plunger	1
44	-	Oil pump body dust cover	1
45	-	Shaft circlips	1
<b>G</b>	<b>8958001361</b>	<b>Foot base assembly kit</b>	
26	-	Spring washer	8
27	-	Hex screw	4
28	-	Footbase assy	2
29	-	Rear wheel	4

Item	Part No	Description	Qty
<b>H</b>	<b>8958001363</b>	<b>Wheel kit</b>	
26	-	Spring washer	4
29	-	Rear wheel	4
<b>I</b>	<b>8958001366</b>	<b>Pressure release lever kit</b>	
37	-	O Ring	1
46	-	O Ring	1
47	-	Pressure release fixed seat	1
48	-	Two speed action pressure release spring	1
49	-	Two speed action pressure release base	1
50	-	Filter net	1
51	-	Internal circlips	1
52	-	Steel ball	1
53	-	O Ring	1
54	-	Pressure release lever	1
55	-	Torsional spring	1
56	-	Rotary knob	1
57	-	Inner hexagon screw	1
<b>J</b>	<b>8958001367</b>	<b>Cylinder head kit</b>	
8	-	Screw	1
9	-	Dust-proof ring	1
10	-	O Ring	1
11	-	Piston guide bushing	1
12	-	Un-seal	1
13	-	O ring	2
<b>K</b>	<b>8958001369</b>	<b>Saddle kit</b>	
59	-	Inner hexagon screw	2
60	8958001410	Rubber pad	1
61	-	Saddle assy	1
<b>L</b>	<b>8958001371</b>	<b>Iron chain kit</b>	
62	-	Spring fastner	4
63	-	Iron chain (5×15×1200)	2
<b>M</b>	<b>8958001372</b>	<b>Tray holder kit</b>	
64	-	Shaft circlips	1
65	8958001411	Tray	1
66	-	Tray holder	1
<b>N</b>	<b>8958001373</b>	<b>Tune up kit (include: 2 (x3), 5 (x2), 9, 10, 12, 13 (x2), 36, 37, 39, 42 (x2), 46, 53)</b>	
	8940166080	Warning label transmission jack	1
	8950900061	Warning label general	1
	8956002282	Warning lift bar label	1
	8956200010	Safety instruction	1
	<b>Recommended accessories</b>		
	8950390000	hydraulic oil	1.0 L